

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

ENGINE OIL LEVEL: topping up/filling (1/2)



1.2 16V

Topping up/filling

The vehicle must be parked on level ground and the engine should be cold (for instance, before the engine is started up for the first time in the day).

Engine oil grade

Refer to the Maintenance Service Booklet for your vehicle.



1.4 - 1.6

1.4 - 1.6

– Unscrew cap 2
– Top up the level (as a guide, the capacity between the minimum and maximum reading on dipstick 1 is between 1.5 and 2 litres, depending on the engine);

– wait approximately 10 minutes to allow the oil to flow into the engine;
– check the level using dipstick 1 (as described above).
Once the level has been read, push the dipstick in as far as it will go.

Do not exceed the MAX level and do not forget to refill dipstick 1 and cap 2.



1.6 16V

1.6 16V

– Unscrew cap 2
– Top up the level (as a guide, the capacity between the minimum and maximum reading on dipstick 1 is between 1.5 and 2 litres, depending on the engine);

– wait approximately 10 minutes to allow the oil to flow into the engine;
– check the level using dipstick 1 (as described above).
Once the level has been read, push the dipstick in as far as it will go.

Do not exceed the MAX level and do not forget to refill dipstick 1 and cap 2.

carmanualsonline.info

[Download PDF version of :](#)
Dacia Sandero User Guide